

**Installation manual  
for  
EWS Wah Board Special**



Step 1: Remove the rubber feet from the Wah and place the screws aside.



Step 2: Place the Wah Board Special over the bottom panel and replace the screws back in. After you have glued the Velcro on the back (not included), it is ready to be set on the pedalboard.