

LIVE TO PLAY LIVE®



JIMDUNLOP.COM

92503011305REVB





**"THE FIRST PEDAL I EVER
PURCHASED WAS A CRYBABY,
25 YEARS AGO. I AM SO
HONORED TO HAVE MY NAME
ON THIS PEDAL AND HOPE
IT BRINGS YOU AS MUCH
FUN AS IT BRINGS ME EVERY
NIGHT ON STAGE."**

A handwritten signature in black ink, appearing to be 'JB' with a stylized flourish.



JB95 JOE BONAMASSA CRY BABY

POWER

The JB95 Cry Baby® can be powered by one 9 volt battery (accessed via the bottom of the pedal), a Dunlop ECB003 AC adapter (ECB003E in Europe) or a Dunlop DCB10 DC Brick power supply.

SETUP INSTRUCTIONS

- Run a shielded instrument cable from your guitar to the Cry Baby's Instrument jack.
- Run another shielded instrument cable from the Cry Baby's Amplifier jack into your amplifier input.
- Turn on the amplifier and begin playing.
- To turn the pedal on/off, push the toe of the pedal down until you feel a "click".
- By rocking your foot back and forth on the pedal, you can change the effect that the JB95 Cry Baby has on the tone of your instrument instantaneously.
- Internal switch (shown in diagram) enables TRUE HARDWIRE BYPASS.

SPECIFICATIONS

Impedance

Input	800 kΩ
Output	10 kΩ

Filter Parameter

Low Pass	290 Hz ~ 310 Hz
High Pass	1400 kHz ~ 1510 kHz

Maximum Level


Input	-8.0 dBV
Output	+10 dBV

Maximum Gain

Heel Down	+16.5 dB @ 1400 Hz ~ 1510 Hz
Toe Down	+16.5 dB @ 290 Hz ~ 310 Hz

Current Draw	1.35 mA
---------------------	---------

Remove bottom plate to access internal TRUE HARDWIRE BYPASS switch, illustrated below in the factory preset "off" position.





**ALSO AVAILABLE FROM DUNLOP:
JOE BONAMASSA SIGNATURE FUZZ FACE.
VISIT JIMDUNLOP.COM FOR MORE INFO.**



**DUNLOP MANUFACTURING, INC.
P.O. BOX 846 BENICIA, CA 94510 U.S.A.
TEL: 1-707-745-2722 FAX: 1-707-745-2658**