




HONEY COMB DELUXE



Classic blackface and Voxy tremolo tones with two totally adjustable and foot-switchable speeds in a small footprint.

Controls

JACKS

VOLUME - Controls the output volume. Can be set at unity or a slight boost.

DEPTH - Controls the depth of the tremolo.

SPEED 1 - Controls the speed of the tremolo when the green indicator LED is lit.

SPEED 2 - Controls the speed of the tremolo when the red indicator LED is lit.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 100mA max consumption.

FOOTSWITCHES

LEFT FOOTSWITCH - On/Off switch

RIGHT FOOTSWITCH - Toggles between green speed and red speed.

This pedal contains an internal switch that controls the speed range available. Up is stock speed mode, and down is slow speed mode.

Jacks

INPUT - Jack on the right side of the pedal.

OUTPUT - Jack on the left side of the pedal.