



# THE EMPEROR

**JHS** PEDALS

*True analog bucket brigade Chorus and Vibrato with tap tempo waveform selection and more. Classic modulation with modern amenities.*

## Controls

### FOOTSWITCHES

**BYPASS** - Left footswitch turns the pedal on and off.

**TAP TEMPO** - Right footswitch taps in the speed.

### KNOBS

**VOLUME** - Controls the output volume.

**tone** - Controls the amount of brightness. Left is darker, right is brighter.

**SPEED** - Controls the time/speed of the modulation.

**DEPTH** - Controls how deep or wet the modulation is perceived.

**CHORUS/VIBRATO TOGGLE** - Lets you choose between Chorus and Vibrato

**WAVEFORM TOGGLE** - Choose between Sine, Square, and Triangle waveforms.

### JACKS

**INPUT** - Receives your instrument's signal.

**OUTPUT** - Sends the signal out of the pedal to an amplifier or pedal chain. You can use an optional TRS splitter cable to send your signal to two amps for true stereo modulation.

**TAP/EXP.** - Choose which one you want by the internal switch. In Expression Mode, connect any TRS expression pedal to control the pedal's speed. The speed parameters are preset for realistic rotary speaker sound. In Tap Mode you can set the speed using an external tap tempo pedal.

### INTERNAL SWITCHES

**TBP/BUF** - Choose between true-bypass or buffered bypass.

**TAP/EXP** - Choose between tap or expression for the Tap/Exp. jack.

**POWER** - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 100mA max consumption.