



RUBY RED



Butch Walker's signature 2-in-1 overdrive/boost. No matter what style music you play, the Ruby Red is a powerful tone shaping tool that will offer you everything from tone enhancement to boost, overdrive, distortion, and even fuzz.

Controls

RIGHT SIDE - BOOST

BOOST - Increases volume. Right is louder, left is quieter.

LEFT SIDE - SUPERBOLT

VOLUME - Controls the output volume. Right is louder, left is quieter.

DRIVE - Controls the amount of drive or gain just like a tube amp being cranked at high volumes.

TONE - Increases brightness. Right is brighter, left is darker.

FOOTSWITCHES

RIGHT FOOTSWITCH - Turns Boost on or off.

LEFT FOOTSWITCH - Turns SuperBolt on or off.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 100mA max consumption.

TOGGLES

+ **TOGGLE** - Engages higher gain mode when flipped down.

ORDER TOGGLE - Selects the order of the effects. Right is Boost > SuperBolt, left is SuperBolt > Boost. When the Boost is first it will cause the SuperBolt to be more saturated. When the Boost is second it will cause it to be louder

Jacks

INPUT - Jack on the right side of the pedal.

OUTPUT - Jack on the left side of the pedal.