




SWEET TEA V2



Everything possible, medium to high gain. Classic 808 tube screamer tones and our very own Angry Charlie inside this one compact design.

Controls

Left Side - Angry Charlie

VOLUME - Controls the output volume.

DRIVE - Controls the amount of drive or gain just like a tube amp being cranked at high volumes.

TONE - This is a tone cut like you would find on an amp. Left is brighter, right is darker.

PRESENCE - Just like the presence knob on an amp, this allows you to dial in the perfect amount of high end for compatibility with any amp. It works as a presence cut, left is brighter, right is darker.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 100mA max consumption.

Right Side - JHS 808

VOLUME - Controls the output volume.

DRIVE - Controls the amount of drive or gain just like a tube amp being cranked at high volumes.

TONE - Controls the amount of brightness. Right is brighter, left is darker.

3 WAY GAIN TOGGLE - Down is stock saturated mode, middle is boost mode, and up is crunch mode.

JACKS

INPUT - 1/4" jack on the right side of the pedal.

OUTPUT - 1/4" jack on the left side of the pedal.