



# UNICORN

JHS PEDALS

*When everything has been done and everything has been seen, we bring you the first ever 100% analog signal path Uni-vibe\* Photocell Modulator w/ Tap Tempo.*

## Controls

### FOOTSWITCHES

**Bypass** - Left footswitch turns the pedal on and off.

**Tap Tempo** - Right footswitch taps in the speed/rate.

### KNOBS

**Volume** - Controls the overall output volume.

**Depth** - Controls the intensity of the effect. Left is less effect, right is more.

**Speed** - Controls the speed/rate of the effect. Left is slower, right is faster. Will override the tap-tempo speed when rotated.

**Ratio** - Controls the ratio of the tapped speed. Choose 1/4, dotted 1/8, 1/8, triplets, or a blend in-between. This allows for faster speeds with fewer taps.

**POWER** - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided.  
100mA max consumption.

### JACKS

**Input** - Receives your instrument's signal.

**Output** - Sends the effect to an amplifier or pedal chain.

**TAP/EXP** - Choose which one you want by the internal switch. In Expression Mode, connect any TRS expression pedal to control the pedal's speed. In Tap Mode you can set the speed using an external tap tempo pedal.

### TOGGLE

**Dry/Wet** - Choose between full wet vibrato style or add in the dry signal for the classic Uni-vibe sound.

### INTERNAL SWITCH

**TAP/EXP** - Choose between tap or expression for the TAP/EXP jack.

*We suggest putting the Unicorn before overdrives in your signal chain.*