



The VCR pedal is a first in a new collaboration between PaxAM, Ryan Adams, and JHS Pedals. Inspired by the chorus/reverb tones of The Cure, The Smiths and a hefty dose of 1980's angst.

Controls

VOLUME - Controls the output/boost volume.

VOLUME TOGGLE - Toggle just below the Volume knob. Engages the boost circuit when flipped up.

CHORUS - Controls the amount of chorus.

Turning the knob to the left decreases the rate and increases the mix. Turning the knob to the right increases the rate and decreases the mix.

CHORUS TOGGLE - Toggle just below the Chorus knob. Engages the chorus effect when flipped up.

REVERB - Controls the reverb mix. Left is less mix and right is more mix.

REVERB TOGGLE - Toggle just below the Reverb knob. Engages the reverb effect when flipped up.

LO-FI SWITCH - Switch on the backside of the pedal that engages a lo-fi, mid range sound on the overall tone of the pedal.

Jacks

INPUT - Jack on the right side of the pedal.

OUTPUT - Jack on the left side of the pedal.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 80mA max consumption.