

THANK YOU FOR SPENDING YOUR TIME WITH US.

PLEASE VISIT [RKFX.COM](http://RKFX.COM)  
FOR OUR FULL LINE OF PRODUCTS, DEMOS,  
WARRANTY INFORMATION & MORE



**KEELEY**  
ELECTRONICS

**HOOKE REVERB**  
NEO VINTAGE SPRING REVERBERATOR

**TONE:**  
SPRING MODE: TONE CONTROL  
FUGUE MODE: HIGH OCTAVE  
VERB+TREM MODE: TREMOLO RATE

**SPRING:**  
SPRING MODE: SPRING LOOSENESS  
FUGUE MODE: LOW OCTAVE  
VERB+TREM MODE: TREMOLO DEPTH

**FOOTSWITCH:**  
TURNS EFFECT ON AND OFF



**REVERB:**  
REVERB LEVEL

**LEVEL:**  
CONTROLS OUTPUT  
LEVEL OF EFFECT.

**MODE SELECT**  
FUGUE:  
ETHEREAL CHURCH ORGAN  
SOUNDS FROM OCTAVE UP/DOWN  
REVERB WITH NO DRY SIGNAL

**SPRING:**  
CLASSIC, NATURAL SOUNDING  
SPRING REVERB

**VERB+TREM:**  
AMPLIFIER-LIKE  
REVERB & TREMOLO

**TONE:**  
VIBRATO MODE: VIBRATO RATE  
SPRING/PLATE MODE: TONE  
VERB+TREM MODE: TREMOLO RATE

**SPRING:**  
VIBRATO MODE: VIBRATO DEPTH  
SPRING/PLATE MODE: SPRING/PLATE  
BLEND  
VERB+TREM MODE: TREMOLO DEPTH

**FOOTSWITCH:**  
TURNS EFFECT ON AND OFF



**REVERB:**  
REVERB LEVEL

**LEVEL:**  
CONTROLS OUTPUT  
LEVEL OF EFFECT.

**MODE SELECT:**  
VIBRATO:  
SPRING REVERB WITH  
PITCH BENDING VIBRATO  
PLACED BEFORE

**SPRING/PLATE:**  
BLEND OF SPRING  
AND PLATE REVERB

**LONG VERB+TREM:**  
TREM AND VERB WITH LONG DECAY

## BANK 1

THIS IS THE FACTORY  
DEFAULT MODE.  
IT IS ACTIVE WHEN THE INTERNAL  
SWITCH IS SET TO BANK 1.

**EFFECT TYPE: SPRING REVERB WITH 3 MODES**

**POWER REQUIREMENT: 9VDC CENTER NEGATIVE, 65mA+ POWER SUPPLY REQUIRED**

**INPUT/OUTPUT: MONO INSTRUMENT INPUT, MONO OUTPUT**

## BANK 2

ACCESS THIS MODE BY  
SWITCHING THE INTERNAL  
SWITCH FROM  
BANK 1 TO BANK 2

**SWITCH 1 - BANK 1 TO BANK 2**

**SWITCH 2 - FILTERS THE OUTPUT FOR A VINTAGE OR MODERN TONE**