



T-M-18
distortion

Owner's Manual

All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

CONTROLS

VOL - Controls the output volume.

GAIN - Controls the amount of gain.

TONE - Make the tone of pedal brightens or darkens. Colckwise is brighter, anticlockwise is darker.

MOD - Clipping model selection. Up is symmetric mode, down is asymmetrical model.

SWITCH

FOOT SWITCH - turn on/off the pedal.

JACKS

INPUT - 1/4" jack on the input side.

OUPUT - 1/4" jack on the output side.

POWER

This pedal should be operate at 9V DC Negative Center .
If the use of other specifications of the power supply
cause damage. Your warranty will be voided.