

HOW DOES IT WORK?

Volume - Controls the output volume.

Gain - Controls the amount of gain in the circuit.

Tone - A typical tone control. Straight up is flat. To the left darkens your tone, and to the right brightens it.

Blend- Dial in how much of the overdrive circuit comes through. Think of it as a clean cut. When the knob is turned all the way down, you have the most clean signal.

Clip - A two-way switch to alter the clipping style. Flip it down for symmetrical (Lower gain, more open sounds; up for asymmetrical (Higher gain, more compressed sounds).

POWER REQUIREMENTS

9V Center Negative - Using anything else will ruin your pedal and void the warranty. Consumes 59mA.

WARRANTY

All Westminster Effects carry a limited lifetime warranty for pedals sold within the United States and a one-year warranty for pedals sold internationally, for workmanship and components. The warranty does not cover misuse or damage due to accidents. Tampering with components such as trim pots voids the warranty.