

## HOW DOES IT WORK?

**Level** - Controls the output volume.

**Ratio** - Controls the amount of compression.

**Threshold** - How loud the signal has to be before compression is applied. Interacts with the Release control.

**Release** - How soon compression stops after the signal dips below the Threshold.

**Attack** - How quickly the compressor starts to work

**Voice** - Tames the treble frequencies.

Flip to the left for brighter and right to make your tone darker.

## POWER REQUIREMENTS

**9V Center Negative** - Using anything else will ruin your pedal and void the warranty. Consumes 47mA.

## WARRANTY

All Westminster Effects carry a limited lifetime warranty for pedals sold within the United States and a one-year warranty for pedals sold internationally, for workmanship and components. The warranty does not cover misuse or damage due to accidents. Tampering with components such as trim pots voids the warranty.