



# Ghost Echo Reverb

## Ghost Echo Reverb

The Ghost Echo Reverb is designed to emulate a vintage reverb unit. It's capable of providing a little atmosphere all the way through to vast depths. The attack control sets the delay of the initial pick attack on the wet signal only. When playing staccato this registers as a slap back type echo hitting the reverb but when playing fluid lines it adds a massive depth and "fattens" up the sound. The dwell control is a fine tune function that enhances the decay. At first it may seem like it's not there but back it off and you'll miss it. The depth controls the intensity of the reverb.

## Controls

**Depth-** Sets reverb intensity (level of wet signal)

**Dwell-** Enhances the length of the decay. As the depth is increased the dwell should be decreased. Increasing the dwell with the depth set high will result self-oscillation due to the signal slamming the reverb "tank". It's actually pretty cool.

**Attack-** Sets the delay of the pick attack on the wet signal only.

**Power:** Any standard regulated 9-volt DC power supply with a negative center 2.1mm barrel. Do not run at higher voltages!

**Questions? Concerns?:** EQdevices@yahoo.com



# Ghost Echo Reverb

## Ghost Echo Reverb

The Ghost Echo Reverb is designed to emulate a vintage reverb unit. It's capable of providing a little atmosphere all the way through to vast depths. The attack control sets the delay of the initial pick attack on the wet signal only. When playing staccato this registers as a slap back type echo hitting the reverb but when playing fluid lines it adds a massive depth and "fattens" up the sound. The dwell control is a fine tune function that enhances the decay. At first it may seem like it's not there but back it off and you'll miss it. The depth controls the intensity of the reverb.

## Controls

**Depth-** Sets reverb intensity (level of wet signal)

**Dwell-** Enhances the length of the decay. As the depth is increased the dwell should be decreased. Increasing the dwell with the depth set high will result self-oscillation due to the signal slamming the reverb "tank". It's actually pretty cool.

**Attack-** Sets the delay of the pick attack on the wet signal only.

**Power:** Any standard regulated 9-volt DC power supply with a negative center 2.1mm barrel. Do not run at higher voltages!

**Questions? Concerns?:** EQdevices@yahoo.com