

# LEVITATION

Have you ever wanted your tone to soar like a majestic eagle in a vast canyon? Perhaps you are a simpler mortal and just want your tone to echo like the cries of a sparrow in a small room... Now you can do both like a champ plus a whole lot more! Welcome to your new levitation reverberation machine, designed for the Levitation music festival! This Levitation device is a vintage voiced reverb that aims to fit somewhere between dirty sixties chambers, classic spring and the big, ringing plate reverbs of days gone by. Four knobs and one switch control quite a bit more than you'd expect. Want a slap back small room sound? Set all of your controls to the minimum and use the mix to dial in the sound of room devoid of any thing but a guitar and amp. Want to revel in infinite spatial oscillations? Flip the toggle to long, turn up the atmosphere and decay then tune out. Dial in a bright chiming slap back by turning the tone all the way counter clockwise and reducing the decay. Dime everything for a rattling, full-bandwidth assault. You are only limited by your imagination, bro! Each of these little Levitation machines are made one at a time, part by part, wire by wire in the hamburger capital of the world, Akron, Ohio.

## Controls

**Length** (Toggle)- Broad stroke control for decay time. Shorter to left, longer to the right.

**Decay**- Controls the length of the reverb decay. Longer clockwise, shorter counter clockwise.

**Atmosphere**- This is a harmonic regeneration control, it feeds the upper frequencies of the reverb trails back through to create a more harmonic (ringing) reverb. More atmosphere clockwise, less counter clockwise.

**Mix**- This controls how much wet signal is blended in with the dry. More reverb clockwise, less counter clockwise.

**Tone**- This is an input bandwidth control for the reverberated signal. All the way counter clockwise reduces all low end content to make a brighter reverb, turning counter clockwise allows more low end to pass through resulting in a fuller reverberated tone.

## Power

A standard 9 volt DC power supply intended for musical instruments with a negative center 2.1mm barrel. No batteries accepted.

## Suggested Placement

After all dirt and modulation, before signal boosters and into a clean amp. But, hey, these are only suggestions, ya know? It's yours now so do as you wish.