TONE CONTROL

GAIN -



LEVEL:

 Controls output level of the pedal. Turn up above unity for added boost effect.

1962

EFFECT TYPE:

Power Requirement:

9V Battery or 9VDC Center Negative Power Supply Required

Input/Output:

Mono Instrunment In, Mono Instrument Out

