

### SPONGY / BOLD Mode Switch:

In SPONGY the voltage is reduced producing a sagged, spongy fuzz sound.

### LEVEL:

Controls final output level of the pedal. Go higher than unity to get an added boost effect.

### FUZZ:

Controls amount of fuzz. Turn to the right for more.



**BLACKTOP**

#### EFFECT TYPE:

FUZZ, Vintage Silicon

#### Power Requirement:

9V Battery or 9VDC Center  
Negative Power Supply

#### Input/Output:

Mono Instrument In,  
Mono Instrument Out