

**DECAY**: decay time of reverb, longer to right

TONE: tone control, left for dark, right for bright

BLEND: wet / dry, left for dry, right for wet

TIME: Delay time up to 950ms, right for longer

REGEN: number of repeats, right for more

LEVEL: output level of the pedal

MORPH: Works Differently in all 3 modes.

- MODULATED: controls the depth of chorus and predelay

- PLATE: controls predelay, up to 200ms

SHIMMER: Controls Level of Octave



