HORSEPOWER



☑ New Slam Control

✓ Volume control for Level matching Or Boost

M Hand built in the USA

☑ Abuse resistant steel case

☑ Completely snob approved!

Delay Time is Adjustable with a Passive Volume Pedal
Via the Control Jack



HOW TO ECHO

OUTPUT -- Plug in amp or effect you plan on using after the MR ECHO in here....Reverb units sound great here. Output impedance is less than 10k. CONTROL -- Plug in any PASSIVE volume pedal's output in here for hands free control over the delay time.....The DELAY control knob is then used to set the max range.

9VDC -- Plug in 9 volt DC adaptor in here for power. It will bypass the battery when plugged in. Current draw is 36ma max. Pay close attention to the Polarity!! Use regulated power adaptor

> INPUT -- Plug your guitar or effect you plan on using in front of the MR ECHO in here. It works best towards the end of the effects chain. Plugging in here also turns the battery on Input impedance is over 1 meg.

VOLUME -- Sets the overall output level. Use to match the volume or as a very slight boost

MIX -- Sets the balance between the echo and straight signal. 12:00 setting is a 50/50 mix.

REPEAT -- Controls the number of echos from one repeat to infinite.

BYPASS -- Switches effect in and out of the singnal path. The LED wil glow when activated.

DELAY -- Sets the delay time range. from 30ms to 550ms

SLAM -- Active only when the SLAM foot switch is depressed. It adjusts the number of added repeats, from none to infinite.

SLAM -- It's a momentary switch that when depressed sets the delay time to 30ms and activates the SLAM control. It returns to normal when your foot is removed



Warranted for one year from date of purchase

TONE BY ANY MEANS NECESSAR

WWW.SIBFX.COM